

PRINTER DRIVER GUIDE Ver.1.10

(For Windows® CP-M1 series)

The driver guide only describes the changes of Ver.1.10.

Please refer to CPM1DriverGuideE_V100.pdf for other details.

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe, Adobe Photoshop are registered trademarks of Adobe Systems.

The various software packages mentioned in this manual are the registered trademarks of their respective companies.

Refer to the following web site to check the latest version of the printer driver.

http://www.mitsubishielectric.co.jp/ldg/ja/products/visual/lineup/printer/photo/download_01_english.html

You can not use different version of the driver at the same time.

When the driver has already installed, uninstall it and then install this driver.

System requirements

Please refer to CPM1DriverGuideE_V100.pdf for system requirements.

Install / Uninstall

Please refer to CPM1DriverGuideE_V100.pdf for installation and uninstallation procedures.

Function explanation

2. Option setting dialog.

2) Print Mode

Printing mode is set.

Auto: Prints with appropriate speed depending on the image.

Fast: Prints with high speed.



Prohibition matter



We prohibit Reverse Engineering, decompiling or reverse assembling of this driver software.



Exemption from responsibility



Occasionally, this software does not operate normally depending on operating environment.

Moreover, Mitsubishi Electric Co. will not assume any responsibility for damage (including, but not limited to, lost profit or damage caused from special circumstances etc.) occurring during the use of this driver.